




TENT PARTS



To order, please call 877-777-0220

PART #1: Black, plastic, snap-in cap for beam ends

PART #2: This part is the upper corner leg and black support beam connector. Tent Part #2 has three sizes. You must measure from the white to white part to determine what size you need. Possible sizes are 42", 42 1/2", or 43 3/4"

PART #3: Lower canopy support beam (40 1/2" length)

PART #4: Black, square, plastic canopy support beam connector

PART #5: Upper canopy support beam (38 3/4" length)

PART #6: Corner support beam (21 1/2" length)

PART #7: Scissor beam (36" length)

PART #8: Black, canopy top, center vertex connector

PART #9: Black, sliding leg, joint connector, and metal o-ring lock

PART #10: Black, square, plastic let insert

PART #11: Extending lower leg and foot. Tent Part #11 has two sizes. Possible sizes are 44" and 45 1/4"

PART #12: One set of nuts and bolts with small washer

PART #13: Plastic spacer



TENT PARTS

To order, please call 877-777-0220



PART #1




PART #2



PART #12
Nuts and Bolts



PART #13
Plastic Spacer



PART #3




PART #4



PART #5



PART #6



PART #7



PART #8



PART #9



PART #10



PART #11